


STATE	PROJECT NUMBER	SECTION NO.	SHEET NO.
ND	BRO-8-010(036)009	170	40



NOTE:
For double acting or single acting diesel hammers, calculate the bearing resistance of piles by the following formula:

$$\Phi R_n = \frac{4.5E}{S + 0.2} \times \frac{W + 0.2M}{W + M}$$

Where:
 ΦR_n = Nominal pile bearing resistance, in pounds. The Φ factor is included in equation.
 W = Weight of striking parts (ram), in pounds.
 M = Weight of parts being driven, in pounds. Includes pile weight, anvil (if any), driving cap, etc.
 E = Energy per blow, in foot-pounds.
 S = Average penetration of pile in inches per blow for last ten blows.

Drive the HP10 x 42 Pile to a bearing resistance of 105 tons.
 Drive the HP12 x 53 Pile to a bearing resistance of 130 tons.
 Drive the HP14 x 73 Pile to a bearing resistance of 180 tons.

* Do not drive abutment piling until all constructed embankment is in place.

PILING LAYOUT



Elevations shown are to top of finished concrete.
BEARING ELEVATIONS

PILE COORDINATES			
	PILE	NORTHING	EASTING
WEST APPR SLAB	1	459,765.91	2,823,133.42
	4	459,735.95	2,823,134.94
ABUT 1	1	459,766.42	2,823,153.42
	5	459,737.46	2,823,154.88
PIER 2	1	459,770.46	2,823,233.32
	7	459,741.50	2,823,234.78
PIER 3	1	459,774.51	2,823,313.21
	7	459,745.54	2,823,314.68
ABUT 4	1	459,778.55	2,823,393.11
	5	459,749.59	2,823,394.58
EAST APPR SLAB	1	459,780.06	2,823,413.06
	4	459,750.10	2,823,414.58

This drawing is preliminary and not for construction or implementation purposes.

MAPLE RIVER

PILING LAYOUT & BEARING DETAILS