

# SHARETHE

**Agriculture Transportation Safety** 



## **Safety Procedures for MovingSelf-Propelled Machines on Public Roads**

- Empty combine grain tank
  - The added weight could change the operational dynamics of system and cause safety concerns when crossing bridges.
- Secure head in raised position
- Remove wide heads and transport on header wagon
- Lock brake pedals
- Move augers, and other components into the transport position
- Check SMV, hazard lights, and mirrors for function and visibility





### **Other Transport Hazards**

#### Overhead clearances

- Low hanging power lines
- Bridges

#### Hazardous materials

- Anhydrous ammonia
- Chemicals
- Manure

#### Sharp turns

- Ditches
- Speed
- Long equipment





